



BW-BHR4530	45.	22.	30.	3.6 4.5 4.6 4.7 6.0 8.0	□□ □□□□
BW-BHR5330	53.	30.	30.		
BW-BHR5530	55.	22.	30.		
BW-BHR5545	55.	22.	45.		
BW-BHR5545	55.	30.	45.		
BW-BHR5545	55.	39.	45.		
BW-BHR5545	55.	53.	45.		
BW-BHR5545	55.	55.	45.		
BW-BHR5560	55.	43.	60.		
BW-BHR8060	80	55.	60.		
BW-BHR5972	59.	53.	72.		
BW-BHR6077.	60.	53.	99.		
BW-BHR3307	33.	6.	7.	□□□□	
BW-BHR3310	33.	6.	10.		
BW-BHR4910	49.	6.	10.		
BW-BHR4915	49.	6.	15.		
BW-BHR4920	49.	6.	20.		

□□□□□□□□□□□□

□□	□□		□□	□□□□
	□□	□□		
BW-BH12514	5.	125.	3.	14.
BW-BH12514			4.	14.
BW-BH12520			3.	20.
BW-BH12520			4.	20.
BW-BH12530	5.	125.	3.	30.
BW-BH15014	6.	150.	4.	14.
BW-BH12520	6.	150.	4.	20.
BW-BH15045	6.	150.	3.	45.
BW-BH15030			4.	30.
BW-BH20045	8.	200.	4.	45.
BW-BH20030			6.	30.
BW-BH25045	10.	250.	5.	45.
BW-BH25030			6.	30.
BW-BH30045	12.	300	6.	45.
BW-BH30030			9.	30.

BW-BH35045	14.	350.	9.	45.
BW-BH35030			12.	30.

□□□□□□□□□□□□□□□□□□

□□□□

5□□□□□□□□□□□□□□□□□□



**Boreway Machinery Co.,Ltd**  
[www.diamondtools.top](http://www.diamondtools.top)  
[www.boreway.net](http://www.boreway.net)

□□□


□□□□□□□□□□□□□□□□





□□□□

## Fujian Nanan *boreway* Machinery Co.,Ltd.

 Shuitou Town 362342 Quanzhou, Fujian, China □□□□□3605□

 □□□ □+86□595-86990206 /  □□□□+86□595-86990220

 □□/ **WhatsApp** /□□□□+ 86□ 18650679939.

 □□□□□ **boreway@boreway.com.**

 **Lyon Chang**