


BW-BHR4530	45.	22.	30.	3.6 4.5 4.6 4.7 6.0 8.0	□□□ □□□□	
BW-BHR5330	53.	30.	30.			
BW-BHR5530	55.	22.	30.			
BW-BHR5545	55.	22.	45.			
BW-BHR5545	55.	30.	45.			
BW-BHR5545	55.	39.	45.			
BW-BHR5545	55.	53.	45.			
BW-BHR5545	55.	55.	45.			
BW-BHR5560.	55.	43.	60.			
BW-BHR8060	80	55.	60.			
BW-BHR5972	59.	53.	72.			
BW-BHR6077.	60.	53.	99.			
BW-BHR3307	33.	6.	7.			□□
BW-BHR3310.	33.	6.	10.			
BW-BHR4910	49.	6.	10.			
BW-BHR4915	49.	6.	15.			
BW-BHR4920	49.	6.	20.			

□□□□□


□□□□□□□□□□□□□□



□□□

□□□□□□□□□□□□□□

□□ **LAVINA** □□□□□□ □□□□□□□□□□□□□□□□□□□□□□



□□□□





Fujian Nanan *boreway*® Machinery Co.,Ltd.



Shuatou Town 362342 Quanzhou, Fujian, China 360500



+86 595-86990206 /



+86 595-86990220



/ **WhatsApp** / + 86 18650679939.



boreway@boreway.com.



Lyon Chang