

180 #

180 #


180 #

00000	Girt
BW 0000 -00	30 # / 60 # / 80 # / 120 # / 180 # / 240 # / 320 #


36# 46# 60# 80# 100# 120# 180# 220#

Metal Segment

Frankfurt Block



boreway®



Boreway Machinery Co.,Ltd
www.diamondtools.top
www.boreway.net

boreway®



Boreway Machinery Co.,Ltd
www.diamondtools.top
www.boreway.net

boreway®



Boreway Machinery Co.,Ltd
www.diamondtools.top
www.boreway.net

說明書:

1 請仔細閱讀說明書，以便正確安裝和調整。

2 請確保切削速度、進給量、切削深度等參數符合說明書的要求，以獲得最佳的加工效果。

3 請定期檢查和更換磨損的刀片，以確保加工精度。

4 180 # 請注意，本說明書僅供參考，具體的安裝和調整方法請參閱說明書，並根據實際情況進行調整。



□□□□□□:

Suzhou Stonemate Machinery Co.,Ltd products are well accepted from the customers all over the world, such as Asia, Europe, U.S.A. Mid-east ,India,and so on.



- For sample or small orders, products could be sent by express, TNT, DHL, UPS, FedEx, EMS etc.
- For large orders, shipping by sea or air is recommended. By our long-term cooperate agent or your appointed forward.
- By sea, port of loading: Shanghai, Ningbo, Xiamen, Qingdao etc.



7-10 working days
WWW.TNT.COM



5-7 working days
WWW.EMS.COM.CN



5-7 working days
WWW.DHL.COM



5-7 working days
WWW.UPS.COM



5-7 working days
WWW.FEDEX.COM

□□□□□ □□□□ □□□:

